Scintillator Counter # Why it was removed from TAGH	Problems Found	What was repaired	Date Taken Out	Date Reinstalled
83 Loose scintillator	Scintillator no longer securely attached to light guide	scintillator reattached, plastic endpiece added	7/10/2019	7/17/2019
84 Loose scintillator	Scintillator no longer securely attached to light guide	scintillator reattached, plastic endpiece added	7/10/2019	7/17/2019
92 Loose scintillator	Scintillator no longer securely attached to light guide, scintillator bent	scintillator replaced, plastic endpiece added	7/10/2019	7/17/2019
98 Loose scintillator	Scintillator no longer securely attached to light guide	scintillator reattached, plastic endpiece added	7/17/2019	7/26/2019
101 Loose scintillator	Scintillator no longer securely attached to light guide	scintillator reattached, plastic endpiece added	7/17/2019	7/26/2019
110 Loose scintillator	Scintillator no longer securely attached to light guide	scintillator reattached, plastic endpiece added	7/17/2019	7/26/2019
113 Loose scintillator	Scintillator broken in two towards base	scintillator replaced, plastic endpiece added	6/10/2019	7/2/2019
116 Loose scintillator	Scintillator broken in two towards base, 1 disconnected wire at the circuit board	scintillator replaced, wire reattached, plastic endpiece added	6/10/2019	7/2/2019
119 Loose scintillator	Scintillator no longer securely attached to light guide	scintillator reattached, plastic endpiece added	7/2/2019	7/10/2019
123 Loose scintillator	Scintillator no longer securely attached to light guide, large air bubble between light-guide and PMT	scintillator reattached, light-guide and PMT were replaced for one without a bubble	7/10/2019	7/17/2019
125 Loose scintillator	Scintillator no longer securely attached to light guide, 1 disconnected wire at the circuit board	scintillator reattached, wire reattached, plastic endpiece added	6/10/2019	7/2/2019
126 Loose scintillator	Scintillator no longer securely attached to light guide	scintillator reattached, plastic endpiece added	7/10/2019	7/17/2019
138 Loose scintillator	Scintillator no longer securely attached to light guide	scintillator reattached, plastic endpiece added	7/10/2019	7/17/2019
144 Loose scintillator	Scintillator no longer securely attached to light guide	scintillator reattached, plastic endpiece added	6/10/2019	7/2/2019
161 Loose scintillator	Scintillator no longer securely attached to light guide	scintillator reattached, plastic endpiece added	6/10/2019	7/2/2019
170 Loose scintillator	Scintillator no longer securely attached to light guide, very cloudy light-guide	scintillator reattached, plastic endpiece added	7/17/2019	7/26/2019
	Scintillator no longer securely attached to light guide, 1 disconnected wire at the circuit board, amplifie	r		
184 Loose scintillator	and divider not proper distance apart (was an 1/8th an inch apart)	scintillator reattached, plastic endpiece added, wire reconnected	7/10/2019	7/17/2019
187 Loose scintillator	Scintillator no longer securely attached to light guide	scintillator reattached, plastic endpiece added	7/2/2019	7/10/2019
196 Loose scintillator	Scintillator no longer securely attached to light guide, scratches on scintillator around base	scintillator replaced, plastic endpiece added	7/2/2019	7/10/2019
212 Loose scintillator	Scintillator no longer securely attached to light guide	scintillator reattached, plastic endpiece added	7/2/2019	7/10/2019
228 Loose scintillator	Scintillator no longer securely attached to light guide	scintillator reattached, plastic endpiece added	7/2/2019	7/10/2019
229 Loose scintillator	Scintillator no longer securely attached to light guide	scintillator reattached, plastic endpiece added	7/10/2019	7/17/2019
230 Loose scintillator	Scintillator no longer securely attached to light guide	scintillator reattached, plastic endpiece added	7/10/2019	7/17/2019
231 Loose scintillator	Scintillator no longer securely attached to light guide	scintillator reattached, plastic endpiece added	7/17/2019	7/26/2019