

# **PWO Crystal Production and**

# **Quality Control at SIC**

Dr. Hui YUAN

SIC and JLab. Collaboration meeting, Shanghai, 2018.07.23


#### Outline



- 1. Modified Bridgman method
- 2. PWO crystals production
- 3. PWO quality control
- 4. Summary


## **Crystal Growth**

#### Czochralski



High quality
High cost
High temperature


#### Bridgman




High efficiency Low cost High flexibility

# **PWO Crystal Growth Parameters**

- √ Speed : 0.4-0.6 mm/h
- √ Gradient : 20-50 C/cm
- √ Furnace temp: 1170 C
- √ Seeding temp: 1045 C




Furnace temperature profile



## **PWO CX for PrimEx**

中国科学院上海硅酸盐研究所 Shanghai Institute of Ceramics Chinese Academy of Sciences




2001.5-2002.6, SICCAS provided PrimEx all 1275 PWOs.



## SICCAS PWO CX for PrimEx


中国科学院上海硅酸盐研究所 Shanghai Institute of Ceramics Chinese Academy of Sciences



CERN


## **PWO CX for CMS**


中国科学院上海硅酸盐研究所 Shanghai Institute of Ceramics Chinese Academy of Sciences





中国科学院上海硅酸盐研究所 Shanghai Institute of Ceramics







#### **Production procedures:**

- 1. Weighting PbO/WO<sub>3</sub> + 150ppm Y
- 2. Polycrystalline
  Mixture sintered/melted
- 3. Shaping Compounds into crucibles with seeds
- 4. Seeding Crucibles into furnace and heated
- Crystal growthSeeding temp reach and growth starts



#### **Production procedures:**

- 6. Ingots
  - After finish, ingots got from crucibles
- 7. Annealing
  - Low temp annealing to remove tension
- 8. Machining
  - Cutting, grounding and polishing
- 9. Test bench
  - Transmittance, light yield and RH
- 10. Products
  - **About 8 weeks needed**



## **Key points:**

1. Lead time: 3-6 months

Furnace tuning, raw material ordering, Pt rental

2. PbO material

**Environmental policy restrict the PbO production** 

3. Uniformity

30 cx in one growth, no forced convention

4. Crystal yield

**Growth \* machining \* performance** 



# **CAS** PWO Quality Control

#### 1. PbO material

For each batch, to grow one sample to verify the quality. Second source may be needed.

#### 2. Uniformity

New furnaces are planned to be set up.

#### 3. Radiation hardness

Gamma-ray irrad facility has been moved. UV irrad will be applied to the ingots to verify its RH.



# **CAS** PWO Quality Control

#### 1. PbO material

For each batch, to grow one sample to verify the quality. Second source may be needed.

#### 2. Uniformity

New furnaces are planned to be set up.

#### 3. Radiation hardness

Gamma-ray irrad facility has been moved. UV irrad will be applied to the ingots to verify its RH.





- 1. The PWO crystals can be produced with the Bridgeman technique.
- 2. Due to the environmental policy, PbO material supply is being reduced, and there is no nearby Gamma ray irrad facility.
- 3. New furnaces are planning to be set up.



# Thanks!

