# Transmission of cookies Update

Maria Patsyuk

## Update


- Transmittance data from Belle II, [1407.3258v1], Eljen is superimposed with our measurements so that one can conclude
  - We measured transmittance <400 nm, which is significantly lower than in other results
  - Epotek cuts at ~300 nm, so 300-400 nm is an important region
- Cost of RTV material vs. sheets
- Light port buy feedthrough ?

## TSE vs. RTV

Geant4 uses attenuation length to characterize materials:


$$T = \exp(-x/L), L = -x / \ln(T)$$


x – thickness of the sample, T - transmittance




attenuation length [cm] TSE3032 **RTV615** EJ650 EJ560 Fresnel corr. for one surface 15 0<sup>⊥⊥</sup> 200 300 500 250 350 400 450 550 600 photon wavelength [nm]

<350 nm – range of difference btw TSE and RTV





## Transmittance for RTV615, 100:10, 20C



[1407.3258v1]

Sample 1: 1.9 mm, 25 C


Sample 4: 3.3 mm, 25 C


Sample 6: 2.3 mm, 25 C

Sample 8: 1.4 mm, 25 C

Measured for interface air-silicone-air, to compare with our results this curve was corrected for Fresnel reflection using factor 0.98 = T(air-FS-air) / T(air-silicone-air)


# Transmittance for RTV and Eljen-560





Absolute measurement: (air-FS-material-FS-air)







Manufacturer has variations in transmission within the same batch

Relative measurement: (air-siliconeair)/air → Fresnel limit is 94%

RTV 2 mm thick cookies








## Plots of relative transmission

#### relative to

- two windows with greasing oil inbetween


Shaded area shows averaging between 3 points

#### Relative to two quartz windows with oil inbetween




Comparison of different mixing ratios using 2 mm thick cookies

#### Relative to two quartz windows with oil inbetween




Comparison of different curing temperatures

#### Relative to two quartz windows with oil inbetween



Old FCAL cookies are very good. Recently purchased Eljen cookies are worse, and slightly worse than ours.

#### Angle dependence for cookie: RTV 100:2.5 100C 2 mm



Cookie 6


## Cost of RTV

Comparison of buying pre-made cookies to buying RTV material:

material needed to equip DIRC [cc]	RTV615 material	Eljen optical interface sheets
$18 \times 2 \times 2 = 72$ cookies (5.2 cm x 15.8 cm) with thickness 0.2 cm	minimal order 12 lb = 5443g, density 1.03 g/cc	size of one sheet: 330mm x 530mm x 2 mm, which makes 20 cookies
~1200	~5300 for \$1626	4 sheets x \$350 = \$1740
extra volume we get for a minimal order	340% (4100 cc)	18% (210 cc = 0.6 sheet)

It is significantly cheaper to buy molding set of RTV615: for about the same money (\$1700) we can get either Eljen sheets with extra 4100 cc (340%) of material or RTV615 (assuming we mold ourselves) with excess of 0.6 sheet (18%).

# Laser feedthrough



### Plans

- Measure transparency for new cookies:
  - Order RTV material and an EJ-560 sheet
  - New molds?

Order feedthrough?

Simulation in GlueX software using Geant4